

ANYLOAD[®]

OCSL

Mini Type Crane Scale

User's Guide v2



TABLE OF CONTENTS

| | |
|-------------------------|---|
| 1. Introduction | 2 |
| 2. Specifications | 2 |
| Features | 3 |
| Specifications | 3 |
| Capacities & Resolution | 3 |
| Schematic Diagram | 4 |
| Dimensions | 4 |
| 3. Operation Guide | 5 |
| Power On | 5 |
| Power Off | 5 |
| Tare | 5 |
| Hold | 6 |
| Unit Switch | 6 |
| Zero | 6 |
| Settings | 7 |
| 4. Troubleshooting | 8 |
| 5. Calibration | 9 |

1. Introduction

Note: Before using the scale, please read this guide and keep this for future reference.

For good performance and precise measurement on daily operation, observe the following safety guides and maintenance recommendations:

- Do NOT overload the scale. This may damage the load cell and will void the warranty.
- Do NOT leave the load hanged on the scale for too long. This will decrease scale's accuracy and shorten the load cell's life span.
- Inspect the shackle and hook before using. Check clips, pins and screws properly fitted and installed.
- Check battery frequently. When scale drained its battery, charge the battery with its dedicated charger or replace it with a new one
- Avoid rotating the scale, this may damage the load cell
- Do NOT use scale under thunder or rain.
- Do NOT attempt to repair the scale by yourself. Contact your local dealer or to the Technical Support.

2. Specifications

FEATURES

This scale is a combination of sound and proven mechanical design, with nowadays' most advanced electronics to provide a superb feature sets. It is versatile, reliable, accurate and easy to operate.

- **Superb Quality.** Strictly in accordance with OIML R76, Chinese GB/T11883-2000 certified quality system.
- **Great Safety.** Quality stainless steel load receptor and Aluminum-casting case to provide high safety level.
- **Newest.** 20mm LCD, visual distance can go to more than 10m
- **Design.** Demountable hook
- **Leading Technology.** SMT technology quality integrated circuit and dedicated weighing load cell and ensures long time stability
- **Smart Power Saving.** 3*AA battery with low power consumption design
- **Portable.** Different color options. Easy to carry


SPECIFICATIONS

| | |
|---------------------|---|
| Accuracy Class | Chinese GB/T 11883-2002 Class III Equivalent to OIML R76 |
| Tare Range | 100% F.S. |
| Auto Zero | ±50% F.S. |
| Manual Zero | ±2% F.S. |
| Zero Tracking | 0.5e/s |
| Reading Stable Time | ≤10 seconds |
| Auto-sleep | When stable and no activities within 3 sec. |
| Auto-off | When stable and no activities within 3 min. |
| Overload | 100% F.S. + 9e |
| Max. Safety Load | 120% F.S. |
| Ultimate Load | 300% F.S. |
| Battery Life | >150 hours |
| Temp. (Op.) | - 10°C ~ + 40°C |
| Humidity (Op.) | ≤90% at 20°C |
| Display | 0.7 inch (17.78mm) numerical |
| Net Weight | 620g |


CAPACITIES & RESOLUTION

| model | max. cap. (kg/lb) | min. cap. (kg/lb) | resolution |
|-----------|----------------------|----------------------|------------|
| OCS-003-L | 30/60 | 0.01/0.02 | 3,000 |
| OCS-005-L | 50/100 | 0.02/0.05 | 2,000 |
| OCS-006-L | 60/120 | 0.02/0.05 | 3,000 |
| OCS-01-L | 100/200 | 0.05/0.1 | 2,000 |
| OCS-012-L | 120/240 | 0.05/0.1 | 2,400 |
| OCS-015-L | 150/300 | 0.05/0.1 | 3,000 |
| OCS-02-L | 200/400 | 0.1/0.2 | 3,000 |
| OCS-03-L | 300/600 | 0.1/0.2 | 3,000 |

SCHEMATIC DIAGRAM




DIMENSIONS




3. Operation Guide


POWER ON

Press  for 1 second to initialize boot up and battery test.

- Screen will show detection message while detecting its load and processing auto-zero.




POWER OFF

Press  for 1 second to power off the scale.


- Display will show power-off message.




TARE


Press  to store the weight as tare.

- "TARE" will appear and weight reading will turn to zero.
- If weight is greater than 100%F.S. or lesser than 0, taring is not allowed.
- If weight reading is not stable or been held, taring is not allowed.
 - Taring will reduce the scale's apparent overloading range. For example, if a 10kg container is tared to a 50kg maximum capacity scale, the new overload weight shall be at 40.18kg (5000 – 1000 + 9 divisions).




HOLD

Press  to lock the weight reading.

- “HOLD” will appear and reading in the display will be frozen.
- Press  again to unlock and scale will read the actual load.
 - “HOLD” will hide and weight reading will resume.




UNIT SWITCH

Press  for 1 second to switch measuring unit between kg, lb and N.

- If scale is in tare or in hold, unit switching is not allowed.



ZERO

Press  for 1 second to zero the scale.

- “ZERO” will appear and weight reading will turn to zero.
- If scale is in tare or load is not stable or in hold, zeroing is not allowed.
- If the weight exceeds the Manual-Zero range, zeroing is not allowed.



SETTINGS

Hold and press **HOLD UNIT** and **TARE ZERO** keys simultaneously for 1 second to enter Settings Mode. SETUP should appear in the display.




Press **TARE ZERO** to enter Auto-off options and press **HOLD UNIT** to select Auto-off option.




- Auto-Off can be set to 0 (disabled), 5 (5min), 15 (15min), 30 (30min) and 60 (60min).

Press **TARE ZERO** to enter Auto-Zero options and press **HOLD UNIT** to select Auto-Zero option.



- Auto-Zero can be set to 0 (disabled), 2 (2%F.S.), 4 (4%F.S.), 10 (10%F.S.), 20 (20%F.S.), 50 (50%F.S.).

Press **TARE ZERO** to enter Manual-Zero options and press **HOLD UNIT** to select Manual Zero option.




- Manual-Zero can also be set to 0 (disabled), 2 (2%F.S.), 4 (4%F.S.), 10 (10%F.S.), 20 (20%F.S.), 50 (50%F.S.).

Press **TARE ZERO** to enter Backlight options and press **HOLD UNIT** to select Backlight option.



- Backlight can be set to off (disabled), 5 (5sec), 15 (15sec), 30 (30sec), 60 (60sec) and on (never).
- When Backlight is set to 5, 15, 30, or 60, the scale will turn off the backlight if the scale is stable and no activities within the set parameters (enumerated above).
- When Backlight is set to off, the backlight is disabled and will never turn on.

- When Backlight is set to on, the scale's backlight will never turn off even if it is stable and no activities on it.

- Press  to exit the Settings mode



4. Troubleshooting

| Symptoms | Possible Causes | Solutions |
|---|---|------------------------------------|
| blank display when On/Off is pressed | discharged battery | replace battery |
| | defective battery | |
| | defective ON/OFF key | press ON/OFF key for longer period |
| no action taken after TARE or HOLD is pressed | defective TARE or HOLD key | clean TARE or HOLD key |
| unstable readings | scale in motion | stabilize the load and scale |
| | scale is damped | dry the scale |
| | dust on PCB board | clean PCB board |
| reading is not in zero without load | unstable system power | longer warm-up time |
| | load-cell was stressed too much or too long | hang the scale in storage |
| large error in weight reading | scale is not zeroed before loading | keep the scale unloaded and reboot |
| | re-calibration needed | re-calibrate the scale |
| | wrong unit | switch to correct unit |

5. Calibration

Version 2 Models:

| Parameters | Operation | Notes |
|--|---|---|
| <p>Setting the division, resolution and scale's max capacity</p> | <p>-Turn off the scale. Press and then release the [ON/OFF] when the display shows "88888", then quickly hold and press the [HOLD] & [TARE] keys until the scale displays "d 0.00 " or "d 0.0". This is the parameter for decimal point.</p> <p>-The maximum capacity parameter should not exceed your load cell's capacity. The unit of this parameter is automatically in kg. If your scale is rated 60lb then the value here should be 30.00kg.</p> <p>-There are 3 resolutions available: E=1, E=2, E=5</p> | <p>-Press [TARE] to go to a submenu</p> <p>-Press [HOLD] to change the decimal point or resolution. Press the [TARE] key to save it.</p> <p>-Press [HOLD] to move to next digit. Press [ON/OFF] to change the value of the selected digit. Press [TARE] to save parameters.</p> |
| <p>Enter Calibration</p> | <p>-Turn off the scale. Press and then release the [ON/OFF] when the display shows "88888", then quickly hold and press the [TARE] key until the scale displays "LoAd0". At this stage, remove all loads from the scale and make sure it is stable before starting the zero calibration.</p> <p>-To start the Zero Calibration, press the [TARE]. When zero calibration is taking place it should show " ---- " then will ask the amount of weights to be used during span calibration</p> <p>-For better calibration results, it is recommended to use weights of at least 80% of scale's max capacity. The test weight's value must be expressed in kg since the scale can only be calibrated in metric unit. For example if the scale is rated 60lb then the weights required should be 20.00kg (take note not in lb unit)</p> <p>-Load the 20.00kg weights on the scale then press [TARE] to start the span calibration. Make sure the load is stable before starting the calibration.</p> <p>-The scale will show " ---- " when span calibration is taking place and will display " End " when the calibration is succeeded.</p> | <p>-The calibration parameters are based only on metric unit (kg). The scale's division, max capacity and test weights value must be expressed in metric (kg)</p> <p>-Press [HOLD] to move to next digit. Press [ON/OFF] to change the value of the selected digit. Press [TARE] to start the span calibration.</p> |

Version 1 Models:

| Options | Display | Operations | Notes |
|------------------------|---------|--|---|
| Enter Calibration Mode | | Hold and press [HOLD] and [TARE] simultaneously, keep pressing until SETUP displays. | Enter Setup Mode <i>(At this stage set the unit of measurement you are going to calibrate, hold & press the[HOLD/UNIT] to switch unit)</i> |
| | SETUP | Press [ON/OFF], [HOLD] and [TARE] simultaneously, keep pressing until SCALE displays. | Enter Calibration Mode |
| | SCALE | Press [TARE]. | |
| Full Scale | _XXXX | Press [HOLD] to change Full Scale and press [TARE] to save setting. | For example, if you set the unit at kg and setting the parameter here to 600 then the full scale should be 600kg else if it was set to lb then the full scale shall be equivalent to 600lb. |
| Resolution | E X | Press [HOLD] to change Resolution and press [TARE] to save setting. | 1/2/5 |
| Decimal Point | Pt X | Press [HOLD] to change Decimal Point and press [TARE] to save setting. | 0: XXXXX 1: XXXX.X 2: XXX.XX 3: XX.XXX |
| Zero Calibration | LoAd0 | Press [TARE] to start zero calibration. | Set the scale to no load status and must be at stable state. |
| | ----- | | |
| Load1 Calibration | _XXXX | Press [HOLD] to change 1st Calibration Weight value. Load the actual weight then press [TARE] to start span calibration. | If using test weight equivalent to full scale (FULL), the calibration shall be finished at this stage. |
| | ----- | | |
| Load2 Calibration | _FULL | Load the 2 nd test weight then press [TARE] to finish the calibration. | If 2 nd test weight is not needed, you can skip this stage by pressing the [ON/OFF] to finish and exit the Calibration. |
| | ----- | | |
| | _End_ | | |

ANYLOAD Weigh & Measure Inc.

Website: www.anyload.com

Email: info@anyload.com

Fax: +1 866 612 9088

North America Toll Free: 1-855-ANYLOAD (269 5623)